


NOTES:

1. INSERT STRAINER BODY AS SHOWN, APPLY PLUM GUM TO INDICATED SURFACE AS REQUIRED
2. INSERT FIBER, TWO RUBBER AND METAL WASHERS AS SHOWN, TIGHTEN HEX NUT TO MAKE A SECURE JOINT
3. INSERT PLASTIC BUSHING IN END OF TAILPIECE AS SHOWN, SLIDE TAILPIECE NUT IN POSITION AS SHOWN AND TIGHTEN

		Haws [®]		1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWS.CO.COM WEBSITE: WWW.HAWS.CO.COM	
				ECN NO. REVISED PER BY: ECN: 5501	MODEL(S) 6455
DRAWN: JN	DATE: 08-02-93	CHK'D.: DP			
APPROVED: NE	DATE: 04/01/20	SCALE: N/A	DRAWING TYPE:	INSTALLATION	SIZE: A
			SHEET 1 OF 1	REVISION 3	