
NOTES:


- 1. HOLD ROUGH-IN DIMENSIONS ±1/4" (6.4mm).
- 2. WHEN INSTALLING THIS UNIT, LOCAL, STATE, OR FEDERAL CODES SHOULD BE ADHERED TO. FOR INSTALLATION HEIGHTS OTHER THAN SHOWN, DIMENSIONS MARKED (*) MUST BE ADJUSTED ACCORDINGLY. INSTALL A TRAP IN THE WASTE LINE AND A SCREWDRIVER STOP IN THE SUPPLY LINE IF REQUIRED.

(NOTES CONTINUED ON NEXT SHEET)



NOTES CONTINUED:

3. ADHESIVE OR STRUCTURAL SCREWS MAY BE USED TO SECURE THE CORNERS OF THE BACK PANEL FOR VANDAL RESISTANCE.



INSTALL TWO TEMPORARY FASTENERS IN THE FINISH WALL AND HANG THE BACK PANEL ON THOSE FASTENERS. MAKE ANY ADJUSTMENTS NECESSARY SO THAT THE BACK PANEL IS LEVEL AND AT THE CORRECT HEIGHT AND HORIZONTAL LOCATION ON THE WALL.

* DIMENSIONS SHOWN ARE FOR ADULT ADA, REFER TO YOUR ELECTRIC WATER COOLER INSTALLATION INSTRUCTIONS FOR ADDITIONAL INSTALLATION HEIGHTS.

STEP 2

INSTALL THE 12XX HANGER BRACKET(S) AND BOTTLE FILLER BRACKET (BP1201-11 AND BP1212 ONLY) AS SHOWN IN THE INSTALLATION INSTRUCTIONS OF YOUR ELECTRIC WATER COOLER.

REMOVE THE TEMPORARY FASTENERS USED TO HANG THE BACK PANEL, AND FOLLOW THE INSTALLATION INSTRUCTIONS OF YOUR ELECTRIC WATER COOLER TO COMPLETE INSTALLATION.



BOTTLE FILLER WALL

BRACKET

1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWSCO.COM WEBSITE: WWW.HAWSCO.COM

ECN: REV. ECN: BY: 6068 JU
DRAWN: DATE: CHKO: JU 03/11/25 JU
ADDRAWN: DATE: CHKO: JU
ADDRAWN: DATE: DATE

BP12XX, INSTALL

PART NUMBER 0510002301 REVISION 1

PAGE 2 OF