






NOTES:





1. HOLD ROUGH-IN DIMENSIONS $\pm 1/8"$ (3.2mm).
2. WHEN INSTALLING THIS UNIT, LOCAL, STATE, OR FEDERAL CODES SHOULD BE ADHERED TO FOR INSTALLATION DIMENSIONS (LOCATIONS), WASTE AND SUPPLY REQUIREMENTS OTHER THAN SHOWN.
3. INSTALLER MUST PROVIDE TRAP FOR PROPER INSTALLATION.
4. REMOVE VALVE FROM PUSH BUTTON TO INSTALL WASTE ELBOW ONTO BOWL. AFTER WASTE ELBOW IS INSTALLED, REINSTALL VALVE AND ADJUST FLOW.
5. REFER TO 5874 SERIES OPERATION AND MAINTENANCE MANUAL FOR PUSH BUTTON AND VALVE INSTALLATION/MAINTENANCE INSTRUCTIONS.
6. REFER TO 1RKHO.H & 2RKHO.H OPERATION AND MAINTENANCE INSTRUCTIONS FOR TRANSFORMER AND SENSOR SETUP.



MODEL 1011HO/1011HPSHO SHOWN
 MODEL 1011HO2/1011HPSHO2 ON SHEET 2
 (ROUGH-IN DIMENSIONS APPLY TO ALL 4 MODELS)

1455 KLEPPE LANE
 SPARKS, NEVADA 89431
 (775) 359-4712 FAX (775) 359-7424
 E-MAIL: HAWS@HAWS.CO.COM
 WEBSITE: WWW.HAWS.CO.COM

ECN NO. 5579	REVISED PER ECN: 5678	BY: DP	MODEL(S)	PART NUMBER
DRAWN: FV	DATE: 09/15/20	CHKD: FV	1011HO/1011HO2/1011HPSHO/1011HPSHO2	0510001066.D
APPROVED: BJM	DATE: 04/23/21		SCALE: 1:1	REVISION 2
			DRAWING TYPE: INSTALLATION	SIZE: A SHEET 1 OF 2



MODEL 1011HO2/1011HPSHO2 SHOWN
MODEL 1011HO/1011HPSHO ON SHEET 1
(SEE SHEET 1 FOR APPLICABLE ROUGH-IN DIMENSIONS)

		1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWSCO.COM WEBSITE: WWW.HAWSCO.COM	
		ECN NO. 5579 DRAWN: FV APPROVED: BJM	REVISED PER: DP ECN: 5678 DATE: 09/15/20 DATE: 04/23/21
SCALE: 1:1		DRAWING TYPE: INSTALLATION	
SIZE: A		SHEET 2 OF 2	