

\* MUST BE USED IN CONJUNCTION WITH 24VAC TRANSFORMER AND SOLENOID



HO SENSOR CAN BE MOUNTED IN EITHER APPLICATION SHOWN BELOW



PANEL CUT-OUT
OLD VERSION

