

HAWS

ELKAY/HALSEY TAYLOR

MURDOCK

OASIS

COOLER DESIGN WITH BOTTLE FILLER



BOTTLE FILLER



- Clean one-material design
- LED light to illuminate the fill area
- Bottle filler opening 12"
- Laminar flow standard
- Approx 17 seconds run time until auto shut-off
- Auto purge after 24 hours of non use to prevent the development of legionella



- Unit will continue to dispense after filter has reached its flow limit
- Mix of metal and plastic design
- LED light illuminating fill area
- 20 second run time until auto shut-off
- Bottle filler opening 12"



- Unit will continue dispense after filter has reached its flow limit
- A mix of metal and plastic design
- Bottle filler opening 12-5/8"
- Listed flow rate of 1 gpm exceeds filter rating



- Unit will continue dispense after filter has reached its flow limit
- A mix of metal and plastic design
- No bottle area light
- Bottle filler opening 10-1/2"
- Un-refined boxy looks

BOTTLE FILLER DISPLAY



- Intuitive LED display educates users when the bottle filler is activated, when the water is being filtered, and how many plastic bottles have been saved (17 oz)
- Display is standard on models that include a bottle filler



- Bottle counter and filter life indicator lights only
- Bottle counter standard (20 oz)






- Bottle counter only (16 oz) is optional



- Bottle counter only is not included on some coolers that include a filter

HAWS	ELKAY/HALSEY TAYLOR	MURDOCK	OASIS
------	---------------------	---------	-------





WATER FILTER

 <ul style="list-style-type: none"> Model 6428 supplies 3000 gal for water cooler and bottle filler 'F' models <ul style="list-style-type: none"> Flow rate is 0.8 to 1.5 gpm Auto water stop when replacing filter Filter replacement will reset filter life Supplied on "F" numbered models 	 <ul style="list-style-type: none"> Model 51300C supplies 3000 gal for some bottle filler models Model 51299C supplies 1500 gal for some water cooler models Must turn water off before replacing 	 <ul style="list-style-type: none"> Model WF1 supplies 1500 gal only when ordered as an option Auto water stop when replacing filter Flow rate of 0.5 gpm 	 <ul style="list-style-type: none"> Model 'Versafilter' supplies 1250 gal only when ordered Model 033926-001 w/head, 033879-001 filter only Auto water stop when replacing filter
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


SMART ENERGY SAVINGS MODE

<ul style="list-style-type: none"> Standard on filtered and bottle filler models Energy-saving feature allows unit to power off the refrigeration portion after 60 minutes of non-use, or when area lights are turned off <ul style="list-style-type: none"> Unit will automatically start back up next time unit is used or lights are turned back on 	<ul style="list-style-type: none"> Only on bottle filler models Must be manually programmed Can only be a set time to be off - does not power down on its own 	<ul style="list-style-type: none"> Not available 	<ul style="list-style-type: none"> Not available
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------	-----------------------------------------------------------------

ROUGH-IN CAPABILITIES

<ul style="list-style-type: none"> Universal retrofit capability over most existing competitor units (see retrofit table below) 			
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------

ROUGH-IN CAPABILITIES

 <div style="background-color:#00AEEF; color:white; padding: 5px; display: inline-block; text-align:center;"> Download Install Drawing </div>	<ul style="list-style-type: none"> All Models starting with HWU 	<ul style="list-style-type: none"> All Models Starting with EB, EI, EMA, EN, EZ, HAC, HVR, LI, LMA, LZ, TB, & TI. Single cooler models starting with VRC & LVR 	<ul style="list-style-type: none"> A171, A171.8, & A172.8UBL Models Note: Water stop valve must be relocated
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------