## FILTER REPLACEMENT INSTRUCTIONS:

**REQUIRED TOOLS**: BIT-INSERT STYLE SCREWDRIVER, SUITABLE BITS FOR ACCESSING THE FILTER (TYPICALLY A T20 TORX, 5/16" NUT DRIVER, OR 5/32" ALLEN/HEX BIT), NOZZLE KEY (INCLUDED).

**CAUTION:** CUT-RESISTANT GLOVES AND SAFETY GLASSES ARE HIGHLY RECOMMENDED FOR PERFORMING THIS WORK.

- REMOVE COVERS ON THE UNIT TO ACCESS THE FILTER. REFER TO MANUAL FOR APPLICABLE MODEL FOR MORE DETAILS.
- 2. WHILE NOT NECESSARY, IT IS RECOMMENDED TO TURN OFF THE WATER SUPPLY TO THE UNIT. BLEED WATER PRESSURE BY ACTIVATING THE BUBBLER OR BOTTLE FILLER.
- REMOVE EXISTING FILTER BY TURNING CLOCKWISE (AS VIEWED FROM ABOVE) THEN PULLING DOWN.
- 4. INSTALL NEW FILTER BY INSERTING INTO FILTER HEAD AND GENTLY ROTATING UNTIL IT SLIPS VERTICALLY INTO PLACE, THEN ROTATE APPROXIMATELY 1/4 TURN COUNTERCLOCKWISE (AS VIEWED FROM ABOVE). IF A CIRCUIT BOARD IS PRESENT, THE SMALL LABEL/ RFID TAG ON THE BACK OF THE FILTER SHOULD FACE THE CIRCUIT BOARD WHEN INSTALLED.
- 5. IF A BOTTLE FILLER IS PRESENT AND INCLUDES THE NOZZLE TYPE SHOWN, REPLACE THE NOZZLE USING THE INCLUDED NOZZLE AND KEY. THIS 1.0 GPM NOZZLE ENSURES THAT THE BOTTLE FILLER FLOW RATE IS APPROPRIATE FOR THE FILTER RATING.
- 6. RE-OPEN THE WATER SUPPLY TO THE UNIT IF IT WAS TURNED OFF. CHECK FOR LEAKS. RUN WATER THROUGH THE UNIT FOR 10 MINUTES IN ORDER TO PROPERLY FLUSH THE FILTER. IT IS NORMAL FOR SOME CARBON PARTICLES TO FLUSH THROUGH THE SYSTEM.
- 7. REPLACE COVERS ON THE UNIT. IF THE UNIT DOES NOT HAVE A FILTER MONITORING SYSTEM, THEN TAKE NOTE OF THE UNIT LOCATION AND DATE OF FILTER CHANGE. MODEL 6445 FILTER SHALL BE REPLACED EVERY 1 YEAR OR 2,500 U.S. GALLONS, WHICHEVER COMES FIRST.

