



NOTES:

- *1. DIMENSIONS MAY VARY ±1/2" (12.7mm).
- 2. IN ORDER TO COMPLY WITH STATE CODES, THE USE OF A VACUUM BREAKER IS REQUIRED WITH ALL HAND HELD EYE/FACE WASH AND BODY SPRAY UNITS (HAWS OFFERS MODEL SP212).
- 3. TO COMPLY WITH ANSI Z358.1-2009 FOR EMERGENCY EYEWASH OR EYE/FACE WASH AND SHOWER EQUIPMENT:
 - UNIT SHALL BE INSTALLED IN ACCORDANCE WITH MANUFACTURER'S INSTRUCTIONS AND ACCEPTABLE PLUMBING PRACTICES.
 - EYEWASH OR EYE/FACE WASH SHALL BE POSITIONED WITH NOZZLES NOT LESS THEN 83.8 CM (33 IN.) AND NO GREATER THAN 114.3 CM (45 IN.) FROM SURFACE ON WHICH USER STANDS AND 15.3 CM (6 IN.) MINIMUM FROM WALL OR NEAREST OBSTRUCTION.



1455 KLEPPE LANE
 SPARKS, NEVADA 89431
 (775) 359-4712 FAX (775) 359-7424
 E-MAIL: HAWS@HAWSCO.COM
 WEBSITE: WWW.HAWSCO.COM

EQ# NO.:	78859789	REV:	MODEL(S):	8904 EYE/FACE WASH BODY SPRAY
DATE:	4/26/07	HR:	INFO FAX DOC #:	28904
CH:	9826983	DATE:	SCALE:	AS SHOWN
APPROVER:		DATE:	GRAND TYPE:	INSTALLATION/BACK
			SIZE:	A
			SHEET:	1 OF 1
			DATE:	06/20/07
			NO:	2080198.D
			REV:	10899A00
			REV:	11