

AN AXION[®] EYEWASH EVERYWHERE



model 7620

AXION[®] EYEPOD[®]

The AXION eyePOD is a faucet-mounted, thermostatically-controlled eyewash that provides facilities with AXION Medically Superior Response[®] eyewash capabilities in an attractive, low profile, cost efficient design.

AXION's ground-breaking designs duplicate the methodology recommended by medical professionals. Inverted wash streams clear the eyes by gently sweeping contaminants away from the vulnerable eye interior and nasal cavity, helping to reduce further victim injury.





WHY AXION® EYEPOD®?

The feature-rich *AXION eyePOD* is the ideal solution for healthcare offices, educational facilities, laboratories, and athletic sites.

MEDICALLY SUPERIOR RESPONSE

The trademarked inverted, laminar flow wash streams provide even, consistent and predictable stream height for greater user comfort.

SLEEK DESIGN

The low-profile, stainless steel exterior is easy to clean and is unobtrusive in any setting.

EASY INSTALLATION

Several industry standard adaptors are included with the *eyePOD*. Simply unscrew the existing aerator and replace it with the *eyePOD*. The unit will allow normal sink functionality when not in use.

BUILT-IN SAFETY

The *eyePOD* features a built-in thermostatic safety valve that automatically turns off the eyewash when the water streams reach 100° F (37° C), diverting all water through the bottom of the unit. When the water falls below 100° F, the eyewash flows are restored.

ANSI/ISEA Z358.1 COMPLIANT

When installed correctly, the *AXION eyePOD* is certified by CSA to meet ANSI/ISEA Z358.1-2014 Standards for Emergency Eyewash and Shower Equipment.

The *AXION eyePOD* is certified by CSA to meet ASME A112.18.1/CSA B125.1 and ANSI/ISEA Z358.1-2014 standards for Emergency Eyewash and Shower Equipment. Product is compliant to NSF 61, California Health and Safety Code 116875 (AB 1953) and NSF/ANSI 372, along with all current Federal Regulations for the disabled including those in the Americans with Disabilities Act when properly installed on an ADA compliant faucet/sink with knee clearance installation.

EASE OF USE



1 The downward orientation of the *eyePOD* eyewash nozzles, when not in use, keeps them free of dust and debris accumulation, and allows your faucet to function normally.



2 Rotating the front of the *eyePOD* one-half turn (in either direction) brings the eyewash nozzles to the top.



3 In the top position, the eyewash nozzles fully activate as an operational eyewash.