

NOTES:


1. MODEL SP21FC EYE/FACE WASH HEAD IS DESIGNED FOR 2.5 GPM FLOW.
2. ASSEMBLY INSTRUCTIONS:

STEP 1. REMOVE OLD EYE/FACE WASH HEAD.

STEP 2. MAKE SURE THREADS ARE CLEAN.

STEP 3. SCREW ON NEW EYE/FACE WASH HEAD UNTIL HAND TIGHT.
DO NOT USE PIPE SEALANT AS THIS COULD DAMAGE THE EYE/FACE WASH HEAD.
 TEFLON TAPE CAN BE USED BUT NOT REQUIRED.

STEP 4. TURN ON VALVE AND CHECK FLOW PATTERN USING EYEWASH GAUGE
 SUCH AS HAWS MODEL 9015 PER ANSI Z358.1.



Haws corporation		INFO FAX : 1-888-FAX-HAWS (1-888-329-4297) 1455 Kleppe Ln, Sparks NV, 89431 Phone: 775-359-4712 Fax: 775-359-7424 Haws Ag Bachweg 3 CH-3401 Burgdorf Switzerland Haws Mfg Pte Ltd 74 Sungai Kadut Loop Singapore 729531 e-mail: Haws@hawsco.com website: www.hawsco.com	
FOR NO. 10/9/03	REVISIONS	DATE	BY
10/9/03			
TITLE: EYE/FACE WASH HEAD SP21FC MODEL: SP21FC INFO FAX DOC # 2772132 SCALE: 1/2" = 1" DRAWING TYPE: INSTALLATION/FABRICATION		PART NUMBER: 0002080376.0 DRAWING NUMBER: 15116A00 REV: 0	