



REPLACEMENT INSTRUCTIONS:

1. **REQUIRED TOOLS:** PHILLIPS SCREWDRIVER (OR 5/16 NUT DRIVER), 7/16" NUT DRIVER, 1/4" BIT DRIVER, T25 TORX BIT, (SUPPLIED), FLAT-HEAD SCREWDRIVER
2. DISCONNECT ELECTRICAL POWER TO UNIT.
3. REMOVE THE COOLER SKIRT.
4. REMOVE THE LOWER BOWL SUPPORT COVER.
5. IF SERVICING A BOTTLE FILLER UNIT, REMOVE THE BOTTLE FILLER (SEE PAGE 2)
6. REMOVE THE BOTTLE FILLER DRAIN BASIN IF APPLICABLE. NOTE THAT A ZIPTIE ON THE LEFT SIDE OF THE UNIT MAY NEED TO BE CUT. THIS ZIPTIE SUPPORTS THE REFRIGERATION COILS FOR SHIPPING AND DOESN'T NEED TO BE REPLACED. THE DRAIN HOSE WILL NEED TO BE DISCONNECTED IN ORDER TO FINISH REMOVING THIS PART.
7. REMOVE THE CAP IF APPLICABLE. NOTE THAT A ZIPTIE ON THE LEFT SIDE OF THE UNIT MAY NEED TO BE CUT. THIS ZIPTIE SUPPORTS THE REFRIGERATION COILS FOR SHIPPING AND DOESN'T NEED TO BE REPLACED.
8. REMOVE THE EVAPORATOR MOUNTING SCREW.
CAUTION: THIS ALLOWS THE EVAPORATOR TO BE SHIFTED SLIGHTLY TO IMPROVE EASE OF THERMOSTAT REPLACEMENT. DO NOT MOVE EVAPORATOR MORE THAN NECESSARY OR A REFRIGERANT TUBE MAY RUPTURE.
9. USING A FLAT-HEAD SCREWDRIVER, PARTIALLY STRAIGHTEN THE END OF THE THERMOSTAT TUBE TO MAKE REMOVAL EASIER.
10. PULL THE THERMOSTAT OUT OF THE EVAPORATOR.
11. REMOVE THE TWO SCREWS HOLDING THE THERMOSTAT BODY TO THE FRAME.
12. REMOVE THE ENTIRE THERMOSTAT FROM THE UNIT.
13. SLIDE THE PLASTIC TUBING OFF THE OLD THERMOSTAT AND PLACE IT ON THE NEW THERMOSTAT TUBE.
14. INSTALL THE NEW THERMOSTAT, TAKING CARE TO BEND OVER THE END AS SHOWN, APPROXIMATELY 1-1/2 INCHES TO LOCK IT IN PLACE.
15. PUSH PUTTY BACK AROUND OPENINGS (TOP AND BOTTOM) IN EVAPORATOR TO SEAL-OFF SENSOR TUBE.
16. SET THE THERMOSTAT BY FOLLOWING THE INSTRUCTIONS ON THE LABEL SURROUNDING THE ADJUSTMENT SCREW.
17. RE-ASSEMBLE THE UNIT. DO NO OVER-TORQUE THE EVAPORATOR MOUNTING SCREW OR IT MAY CAUSE TILTING OF THE EVAPORATOR.
18. RECONNECT ELECTRICAL POWER.



1455 KLEPPE LANE
SPARKS, NEVADA 89431
(775) 359-4712 FAX (775) 359-7424
E-MAIL: HAWS@HAWSO.COM
WEBSITE: WWW.HAWSO.COM


ECN: 5357	REV. ECN: 5357	BY: JL	MODEL(S)	PART NUMBER
DRAWN: JL	DATE: 07/25/19	CHKD: DHP	5810 - REPLACEMENT 12XX THERMOSTAT	0510000960
APPROVED: BM	DATE: 06/27/19	SCALE: 1:24	DRAWING TYPE: INSTALLATION	REVISION 1
SIZE: A				SHEET 1 OF 2

BOTTLE FILLER REMOVAL INSTRUCTIONS:


1. **REQUIRED TOOLS:** PHILLIPS SCREWDRIVER (OR 5/16 NUT DRIVER), 1/4" BIT DRIVER, T25 TORX BIT (SUPPLIED)
2. IF A HI-LO UNIT IS INSTALLED, THE HIGH UNIT MAY NEED TO BE REMOVED IN ORDER TO ACCESS THE MOUNTING SCREW ON THE LEFT SIDE OF THE RIGHT UNIT. REFERENCE COOLER OPERATION AND MAINTENANCE MANUAL.
3. REMOVE BOTH MOUNTING SCREWS.
4. DISCONNECT BOTTLE FILLER INLET TUBING FROM ELBOW CONNECTOR. REMOVE LOWER PIECE OF TUBING INSULATION.
5. SLIDE BOTTLE FILLER UP AND AWAY FROM UPPER MOUNTING BRACKET UNTIL WIRING HARNESS CONNECTOR IS ACCESSIBLE. DISCONNECT THE WIRING HARNESS.

BOTTLE FILLER REPLACEMENT INSTRUCTIONS:


1. ASSEMBLE THE NEW BOTTLE FILLER, FOLLOWING THE STEPS ABOVE BUT IN REVERSE.
2. RE-INSTALL THE HIGH UNIT IF IT WAS PREVIOUSLY REMOVED. REFERENCE COOLER OPERATION AND MAINTENANCE MANUAL.
3. RE-INSTALL THE COOLER SKIRTS.
4. RECONNECT ELECTRICAL POWER TO THE UNIT
5. RUN THE BOTTLE FILLER TO PURGE AIR FROM THE SYSTEM.



BOTTLE FILLER MOUNTING & TUBING CONNECTION



DISCONNECTING & RE-CONNECTING TUBING



WIRING HARNESS CONNECTION (REAR OF BOTTLE FILLER)

		1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWSO.COM WEBSITE: WWW.HAWSO.COM	
		ECN: 5357 REV. ECN: 5357 DRAWN: JL APPROVED: BM	BY: JL DATE: 07/25/19 CHKD: DHP DATE: 06/27/19
© 2019 Haws Corporation - All Rights Reserved. HAWS® and other trademarks used in these materials are the exclusive property of Haws Corporation.		SCALE: 1:24 DRAWING TYPE: INSTALLATION SIZE: A	SHEET 2 OF 2