



THE MODEL 9010 & 9011 SHOWER TEST KITS GUIDE THE WATER TO A FLOOR DRAIN OR CONTAINMENT BUCKET

GENERAL ASSEMBLY INSTRUCTIONS (9010 & 9011):

1. INSERT THE RING IN THE FUNNEL FOLD
2. INSERT RING HOOKS INTO HOLE OF TELESCOPING POLE

MODEL 9011 ONLY:

1. PLACE THE FUNNEL INTO THE SUPPLIED BUCKET (NOT SHOWN) AND ACTIVATE THE SHOWER FOR 6 SECONDS.
2. IF THE WATER LINE IS BELOW THE 2-GALLON BLACK LINE ON THE BUCKET THEN THE SHOWER FLOW RATE IS NON-COMPLIANT.
3. MEASURE THE TEMPERATURE OF THE WATER USING THE SUPPLIED THERMOMETER (NOT SHOWN). ANSI COMPLIANT RANGE IS 60°F - 100°F (15.5°C - 37.7°C)
4. USE THE SUPPLIED TAPE MEASURE (NOT SHOWN) FOR ALL INSTALLATION AND PERFORMANCE MEASUREMENT REQUIREMENTS IN THE ANSI Z358.1 STANDARD.



1455 KLEPPE LANE
SPARKS, NEVADA 89431
(775) 359-4712 FAX (775) 359-7424
E-MAIL: HAWS@HAWSO.COM
WEBSITE: WWW.HAWSO.COM

ECN: 6208	REV. ECN: 6208	BY: RH	MODEL(S) 9010 & 9011 INSTALL ASSEMBLY	PART NUMBER 0002080204.D
DRAWN: RH	DATE: 03/10/25	CHKD: JSLP		REVISION 8
APPROVED: IR	DATE: 03/13/25	SCALE: 1:12	DRAWING TYPE: INSTALLATION	SIZE: A
				SHEET 1 OF 1