

FEATURES & BENEFITS

CONSTRUCTION

Rugged ADA accessible 18 gauge Type 304 Stainless Steel swirl design bowl, 14 gauge Type 304 Stainless Steel bracket and bottle filler, and vandal-resistant bottom plates provides a long lasting unit with added peace of mind.

BOTTLE FILLER

Vandal-resistant, 14-gauge Type 304 stainless steel bottle filler housing with touchless sensor operation and 1 gpm (3.78 L) laminar flow.

FOUNTAIN VALVES

Fountain incorporates touchless sensor operated stainless steel solenoid valves controlled by a transformer for hands-free operation. A pressure regulator is used to adjust the bubbler flow according to incoming water pressures.

BUBBLER HEAD

Polished chrome-plated brass bubbler head with integral laminar flow prevents splashing while providing a superior flow pattern. The integral 11/16" dia. basin shank and stainless anti-rotation roll pin for vandal resistance strength. Shielded, angled stream opening provides a steady source of drinking water at .45 gpm.

VANDAL RESISTANT

The bubbler head, sensor, round bowl, drain strainer and bottom plate are locked in place, discouraging unwanted vandalism, and 30-second obstruction time-out to reduce tampering of sensor.

MOUNTING

3/16" (.47 cm) thick steel mounting plate (sold separately) is larger, thicker and stronger than any other plate in the industry, and shall include the all-thread studs, nuts, and washers which allows for easy installation to a framed wall. (P-trap and stop require rear access)

OPTIONS

- Support Frame: Model 6800 In-wall floor mounted fixture support legs, welded steel 4-bolt floor flanges, and supplied with 'U' bolts and hardware.
- Mounting Plate: Model 6700R, on-wall mounting plate for model 1920.
- Mounting Plate: Model 6700, in-wall mounting plate for model 1920.
- Bottle Filler Stand: Model BTL1001, add-on stainless steel stand to place bottle on when 1920 bottle filler is used.

For more information, visit www.hawsco.com or call (888) 640-4297.



REQUIRED MODELS

1001HO / BP6 / 6700 / 1920HO / BP15

Order these items to make up the Model 1001HO-1920HO touchless fountain with stainless steel back panel, touchless bottle filler with stainless steel back plate, and fountain mounting plate shown above.

FOR INDOOR USE ONLY

SPECIFICATIONS


Model 1001HO-1920HO ADA vandal-resistant wall mounted motion-activated drinking fountain and bottle filler shall include 18 gauge Type 304 Stainless Steel satin finish basin with integral swirl design, 14 gauge Type 304 Stainless Steel wall bracket and bottle filler bracket, 100% lead-free waterways, touchless sensor operated stainless steel solenoid valves with 30-second obstruction time-out controlled by a transformer, polished chrome-plated brass vandal-resistant bubbler head with integral laminar anti-squirt flow, chrome-plated brass vandal-resistant waste strainer, vandal-resistant bottom plates, and 1-1/4" O.D. (3.2 cm) waste pipe. (P-trap and stop require rear access). Manufactured to be lead-free by all known definitions including NSF/ANSI/CAN 61-Section 9, NSF/ANSI/CAN 372, California Proposition 65, and the Federal Safe Drinking Water Act. Product is compliant to California Health and Safety Code 116875 (AB 1953-2006), and 116876 (AB 100) "NSF/ANSI/CAN 61: Q ≤ 1".

The bottle filler requires a mounting plate; either the Haws model 6700 in-wall or the 6700R on-wall support plate.




NOTES:




1. HOLD ROUGH-IN DIMENSIONS $\pm 1/8"$ (3.2mm).
2. WHEN INSTALLING THIS UNIT, LOCAL, STATE, OR FEDERAL CODES SHOULD BE ADHERED TO FOR INSTALLATION DIMENSIONS (LOCATIONS), WASTE AND SUPPLY REQUIREMENTS OTHER THAN SHOWN.
3. INSTALLER MUST PROVIDE TRAP FOR PROPER INSTALLATION.
4. REFER TO 1RKH0.H OPERATION AND MAINTENANCE INSTRUCTIONS FOR TRANSFORMER AND SENSOR SETUP.




FROM SUPPLY
Y-STRAINER
SENSOR WIRING / SUPPLY PLUMBING
SCHEMATIC




SECTION A-A
ROTATED 90° INTO VIEW
BRACKET MOUNTING
DETAIL



6700 MOUNTING PLATE
MUST BE INSTALLED BEFORE FINISH WORK
THIS PLATE IS REQUIRED - SOLD SEPARATELY.



**Haws**[®]


1456 KLEPPE LANE
SPARKS, NEVADA 89431
(775) 359-4712 FAX (775) 359-7424
E-MAIL: HAWS@HAWS.CO.COM
WEBSITE: WWW.HAWS.CO.COM

ECN NO. REVISED PERBY: FV
DATE: 09/28/21
CHKD: BIM
APPROVED: FV

MODEL(S)
1001HO


SCALE: 1:1
DRAWING TYPE: INSTALLATION
SIZE: A
SHEET: 1 OF 1

PART NUMBER
0510002020.D
REVISION: 1






NOTES:


1. SEE SEPARATE INSTALLATION DRAWINGS FOR MOUNTING PLATES AND BACKPANELS
2. WHEN INSTALLING THIS UNIT, LOCAL, STATE OR FEDERAL CODES SHOULD BE ADHERED TO FOR INSTALLATION LOCATIONS, WASTE AND SUPPLY REQUIREMENTS OTHER THAN SHOWN.
- 3 REFER TO 1RKHO.H OPERATION & MAINTENANCE INSTRUCTIONS FOR SENSOR SETUP.



1920HO SERIES MOUNTING HOLE LOCATIONS
(3/8"-16 UNC MOUNTING HARDWARE NOT SUPPLIED)




				1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWS.CO.COM WEBSITE: WWW.HAWS.CO.COM	
EQUIPMENT NO. 1920HO		MODEL(S)		1920HO/1920HPSHO/1920W	
DRAWN BY: B.M.		DATE: 05/10/01		REVISION: 0510001063.D	
APPROVED: B.M.		SCALE: N/A		SHEET 1 OF 6	





MODEL BP15 / BP15HPS

- NOTES:
1. WHEN INSTALLING THIS UNIT, LOCAL, STATE OR FEDERAL CODES SHOULD BE ADHERED TO.




INSTALLATION OVER SINGLE FOUNTAIN

SHOWN FROM REAR

				1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWS.CO.COM WEBSITE: WWW.HAWS.CO.COM	
ECONO	REVISED PER BR:	MODEL(S)	MODEL 1001 AND 1001HPS	PART NUMBER	1001-20
DRAWN	DATE:	DATE:	DATE:	REVISION	0A.1
DESIGNED	DATE:	DATE:	DATE:		
APPROVED	DATE:	SCALE: 1:1	DRAWING TYPE: INSTALLATION	SIZE: A	SHEET 2 OF 2




6700 MOUNTING PLATE
(BEHIND FINISH WALL)
- OR -
6700R RETROFIT PLATE
(ON TOP OF FINISH WALL)



INSTALLATION ABOVE HAWS 1001, 1001HPS,

* IF YOUR FOUNTAIN IS THIS STYLE USE
THESE DIMENSIONS

1. SEE SEPARATE INSTALLATION DRAWINGS
FOR MOUNTING PLATES AND BACKPANELS
2. WHEN INSTALLING THIS UNIT, LOCAL,
STATE OR FEDERAL CODES SHOULD
BE ADHERED TO FOR INSTALLATION
LOCATIONS, WASTE & SUPPLY
REQUIREMENTS OTHER THAN SHOWN.



3/8" PUSH IN TEE
(CONNECT TO
FOUNTAIN SUPPLY)



1455 KLEPPE LANE
SPARKS, NEVADA 89431
(775) 359-4712 FAX (775) 359-7424
E-MAIL: HAWS@HAWSCO.COM
WEBSITE: WWW.HAWSCO.COM

DRAWN BY: -		DATE: -		MODEL(S)	
GEO: 192017		DATE: 192017		MODEL 1001 AND 1001HPS	
APPROVED: -		DATE: -		WITH MODEL 1920 BOTTLE FILLER	
SCALE: N/A		DRAWING TYPE: INSTALLATION		PART NUMBER	
SIZE: A		SHEET: 1 OF 2		1001-20	
				REVISION	
				0A.1	

Technical drawing of a floor table showing top and side views with dimensions and labels.

Top View Dimensions:

- Overall width: 16"
- Overall depth: 406mm
- Distance from top edge to first row of holes: 6-1/2"
- Distance between rows of holes: 165mm
- Distance from side edge to first column of holes: 3"
- Distance between columns of holes: 76mm
- Distance from bottom edge to last row of holes: 7"
- Distance from side edge to last column of holes: 8-1/2"
- Distance from side edge to center of fountain: 216mm

Side View Dimensions:

- Overall height: 5"
- Distance from top edge to first row of holes: 1-27/32"
- Distance between rows of holes: 47mm
- Distance from side edge to first column of holes: 3"
- Distance between columns of holes: 76mm
- Distance from bottom edge to last row of holes: 4"
- Distance from side edge to last column of holes: 102mm
- Distance from side edge to center of fountain: 127mm
- Distance from side edge to last column of holes: 5-1/8"
- Distance from side edge to center of fountain: 130mm
- Distance from side edge to last column of holes: 152mm

Labels and Notes:

- FLOOR TABLE** (top left)
- FOUNTAIN SIDE** (center)
- 3/8"-16 UNC (ALL THREADED HOLES)** (right side)
- MODE FO** (bottom right)
- USE QTY 2 RUBBER SPACERS(QTY 8 SUPPLIED) TO PROVIDE BACK PANEL ST** (bottom left)

*FINISHED WALL
(SEE TOP VIEW)

MODEL SHOWN IS
FOR REF ONLY

HAWS BACKPANEL

MINIMUM OF 1-1/4
(32mm) OF STUD
MUST EXTEND OUT
OF FINISHED WALL.

USE QTY 2 RUBBER SPACERS(QTY 8 SUPPLIED WITH BACK PANEL) ON EACH STUD (QTY 4 SUPPLIED) TO PROVIDE BACK PANEL SUPPORT.

WALL STUDS

FULLY TIGHTEN NUTS—
DURING ROUGH-IN TO
SECURE STUDS IN PLACE

USE OUTER 7/16" HOLES
FOR MODELS 1025, 1047
& 1075 TO MOUNT PLATE
3/8" MOUNTING HARDWARE
(NOT SUPPLIED).

REFERENCE ONLY,
REFER TO TABLE
FOR PROPER
LOCATIONS.

PLATE AND FOUNTAIN
MOUNTING HARDWARE
(3/8"-16 UNC)
SUPPLIED BY HAWS.

TOP VIEW

*FINISH WALL OVER MOUNTING PLATE AND BEHIND BACKPANEL. MAKE SURE THAT FINISHED WALL EXTENDS WITHIN THE BRACKET/BOWL MOUNTING HOLES (TO PROVIDE SURFACE AREA FOR RUBBER SPACERS TO CONTACT).

MODEL	MTG HOLES	"X" DIM
1000	"G"	25-3/8" [645mm]
1001	"G"	25-3/8" [645mm]
1025	"D"	28-1/8" [714mm]
1047	"E"	27-1/2" [699mm]
1075	"E"	28" [711mm]
1105	"H"	34-5/16" [872mm]
1109	"H"	27-5/16" [694mm]
1116	"G"	25-3/8" [645mm]
1109FR	"G"	25-3/8" [645mm]
1109FR	"H"	27-5/16" [694mm]
1075FR	"E"	28" [711mm]
1311	"E"	26-3/4" [679mm]
1107L	"F"	26-3/16" [665mm]
1311FRMCA	"E"	26-3/4" [679mm]

REGARDING CONCRETE/MASONRY WALL MOUNTING: DO NOT SECURE MOUNTING PLATE TO SAME SIDE OF WALL AS FOUNTAIN. AVOID COMPROMISING INTEGRITY OF WALL WHEN ANCHORING FOUNTAIN. IT IS RECOMMENDED THAT INSTALLER CALL TECHNICAL SUPPORT IF THERE ARE ANY QUESTIONS AS TO HOW TO OBTAIN A PROPER ANCHOR IN CONCRETE/MASONRY WALLS. 1-800-766-5612



1455 KLEPPE LANE
SPARKS, NEVADA 89431
(775) 359-4712 FAX (775) 359-7424
E-MAIL: HAWS@HAWSCO.COM
WEBSITE: WWW.HAWSCO.COM

ECN NO.	REVISED PER BY:
ECN: 5172	FV

MODEL(S)

DRAWN:	DATE:	CHK'D
--------	-------	-------

1

APPROVED:	DATE:
WJL	09/03/03

--	--

FV	02/27/17
----	----------

SCALE: 1/5

©2017 Haws Corporation - All Rights Reserved. HAWS® and other trademarks used in these materials are the exclusive property of Haws Corporation.